Hand Sanitizer Dispenser Stand - HSD Series

1. Connect Bottom Upright (the upright with the spring button) to Base bushing using large Philips Head Screw provided.
2. Slide Top Upright over Bottom Upright until you see the spring button "click" into the hole.
3. Connect Dispenser to mounting plate using a minimum of 2 screws. If the holes don't line up with the holes in the mouting plate, use adhesive backing on your dispenser instead.
4a. Frameless Mounting Option - place plate on top of Upright, twist knob through hole in plate and down into Upright and fully tighten.
4b. Frame Mounting Option - screw Frame Assembly to Dispenser/Upright as shown. If frame is not parallel to Base, tighten or loosen the screw inside the Frame.

1.

2.

spring button

3.

If holes do not align, use adhesive backing on dispenser to attach.

4A.

4B.

HSDM-X-SQ-S shown

HSD1114-X-SQ-S shown