


Fixed Width Banner Towers

1. Slide banners over crossbars and "L" brackets (fig. A).
2. Screw 3" standoff onto bases using flathead screw (make sure the slotted bracket is on top) (fig. B-1).
3. Place crossbars in between standoff and upright and screw together (make sure the slotted bracket is on top) (fig. B-2).
4. Screw top crossbars onto uprights using round knobs (fig. C).



Applicable Products:

TR1, TR2, TR3, TR4

