

# Charisma Mini Frame™ - XMIN Series

1. *Optional:* Place joiner plates into frame sides and tighten set screws to secure frame sides.
2. Remove pre-mounted set screw from free end of angle bracket, then connect top/bottom of frame to frame sides. Reinstall the screw.
3. To install the graphic, take corner A with the pull tag on it and press about 6"-10" of silicone into the frame channel. Repeat for the opposite corner B. Repeat for the next corner C. Lastly, repeat for the final corner D.
4. After all corners are pressed in, press the silicone into the frame channel at the mid-points on all four sides. This prevents the graphic from bunching up or stretching too much and will ensure a smooth and tight fit.
5. Lastly, press the silicone areas into the frame, located between the corner and the mid-point.
6. To remove the graphic from the frame, simply pull up on the pull tab.
7. Determine frame location and mount top brackets onto wall. Use optional molly anchors if mounting to drywall.
8. Slide frame onto top brackets. Mount bottom brackets to wall to secure frame. Use optional molly anchors if mounting to drywall.

*NOTE: For assembly purposes, product shown below is a generic frame. Although the number of support bars and size of frame may differ, instructions remain the same.*

