

# Exhibitor Products (Straight Flat Walls™)

Applicable Products:

FW208

1. Connect upright sections together. Shortest upright section should go on top (fig. A).
2. Slide corner bracket over upright until push button clicks into place (fig. B).
3. Slide upright over base upright until push button clicks into place (fig. C).
4. Slide center bracket over center upright until push button clicks into place (fig. D).
5. Slide upright over base upright until push button clicks into place (fig. E).
6. Press bottom crossbar sections in between uprights until push buttons click into place. Short crossbar section with two push buttons should be placed on the left (fig. F).
7. Press top crossbar sections in between uprights until push buttons click into place. Short crossbar section with two push buttons should be placed on the left (fig. G).
8. Slide pillowcase graphic over frame and zipper at bottom to complete unit assembly (not shown).

