

Signholders (Eclipse Convex)

Applicable Products:

VX1

1. Align flathead screws with base and upright holes and screw into place (fig. A).
2. Mount graphic unit onto upright using allen cap screws (fig. B).
3. Insert graphic into left upright channel (fig. C-1). Tuck graphic gently into right upright channel to complete installation (fig. C-2).

