

# Signholders (Eclipse Convex)

Applicable Products:

VX3

1. Screw graphic units together as shown (screw color may differ from instruction sheet) (fig. A).
2. Insert graphic into left upright channel (fig. B-1). Tuck graphic gently into right upright channel to complete installation (fig. B-2).

