

# Signholders (iPad Stand™)

## Applicable Products:

IPDTR (Counter Top)

1. Align upright over base and slide cord through upright and then through the base (fig. A-1)  
Slide upright over base bushing, align holes, and screw into place to secure (fig. A-2).
2. Remove acrylic cover using small tamper-proof key provided. Place tablet inside and reassemble unit (fig. B). If ball joint loosens on back, use the large tamper-proof key to retighten it securely.

