

# Exhibitor Projector Stand

1. Loosen knobs and remove legs from top underside (fig. A).
2. Screw legs into top (fig. B).
3. Insert utility shelf (optional) in between uprights (fig. C-1). Secure with hooks (fig. C-2).
4. Adjust pole to desired height using push buttons.

## Applicable Products:

SPS

