# Formulate 10' Straight - Kit 4

#### FMLT-WS10-04

Formulate<sup>™</sup> is a collection of sophisticated, ergonomically designed exhibit booths. Formulate combines state-of-the-art zipper pillowcase dye-sublimated fabric coverings with advanced lightweight aluminum structures to provide unique design, functionality, and style. The excellence of the Formulate line of displays, hanging structures and products is simply unmatched. Stretch fabric graphics are hand-sewn, durable and dry-cleanable.



We are continually improving and modifying our product range and reserve the right to vary the specifications without prior notice. All dimensions and weights quoted are approximate and we accept no responsibility for variance. E&OE. See Graphic Templates for graphic bleed specifications.

#### features and benefits:

- State-of-the-art 30mm aluminum tube frame with snap button assembly
- Easy to store and ship
- Features 20" wide counter
- Lifetime hardware warranty against manufacturer defects
- Kit includes: one frame, one dye-sublimated zipper pillowcase graphic, stand-off counter, 4ft. graphic header, one Lumina 8-50 watt spotlight, and one wheeled molded OCL and OCH2 storage case
  Countertop holds max 10 lbs / 4.5 kg

### dimensions:

Hardware	Graphic
Assembled unit: 116" w x 95" h x 29.28" d Ladder dimensions: 23.6" w x 92.7" h x 21.2" d Counter dimensions: 20.47" w x 11.81" d Approximate weight (includes graphics): 64.7 lbs / 29.3 kg	Total visual area: 114" w x 91.5"h 4ft. header: 47.25" w x 11.8125"h Stand-off graphic: Top: 21" w x 17.5"h Bottom: 21" w x 38.6875"h
Shipping Shipping dimensions: 1 OCL case: 19"l x 19"w x 56"h 1 OCH2 case: 52"l x 30"w x 15"h Approximate shipping weight (with cases): 106.7 lbs / 48 kg	Refer to related graphic template for more information. Visit: www.exhibitors-handbook.com/ graphic-templates

#### additional information:

Graphic materials: Dye-sublimated zipper pillowcase fabric, 3mm white PVC, 6mm white PVC


Table colors:





www.display-setup-animations.com


Parts Included – Backwall			
Part Label	Qty	Part Code	
5MM STEEL BASE STYLE 2 FOR LINEAR	x2	LN114-S2	
90 DEGREE ELBOW JOINT FOR 30MM TUBING	x2	TC-30-90	
1114MM X 30MM TUBE	x4	WS10-T1	
1270MM X 30MM TUBE	x6	WS10-T2	
(2) 128MM TUBES SWAGED WITH PART TC-30-T	x1	WS10-T4	
(2) 128MM TUBES SWAGED WITH PART TC-30-X	x1	WS10-T5	
1114MM X 30MM TUBE WITH TC-30-T AND TC-30-90B	x2	WS10-T6	
(2) 128MM TUBES SWAGED WITH PART TC-30-T	x1	WS10-T7	
LUMINA 8 50 WATT SPOTLIGHT	x1	LUM-8-C	




Parts Included – 4ft Header				
Part Label	Qty	Part Code		
CKSO STAND OFF WITH NT1	x2	CKSO		
SILVER ANODIZE FINISH 30MM TUBE CLAMP	x2	TC-30		
48.25"W X 12.8136"H GRAPHIC	x1	WHS-41		
620MM LENGTH OF PT EXTRUSION	x1	PT-620		

Parts Included				
Part Label	Qty	Part Code		
520 X 300 X 30 COUNTER	x1	CTWL03		
SILVER ANOXIZE FINISH 30MM TUBE CLAMP	x2	TC-30		
30MM TUBE SECTION	x2	WL-T3		
30MM TUBE SECTION	x1	WL-T12		
30MM TUBE SECTION	x1	WL-T1		
TOP SINTRA GRAPHIC	x1	WLLH-T-G		
BOTTOM SINTRA GRAPHIC	x1	WLLH-G-B		






#### **STEP 1: ASSEMBLE FRAME**



#### **STEP 2: ATTACH FEET**




# 6MM ALLEN KEY Using provided allen key, secure feet to


bottom of frame by screwing bolt.




#### **STEP 3: ATTACH GRAPHIC**




#### **STEP 5: ATTACH HEADER TO BACKWALL**




Once graphic is attached to stand-offs and extrusion, position tube clamps (TC-30) onto backwall.







Using hex key turn bolt clockwise to tighten tube clamps, securing graphic header to backwall.







Attach graphic to stand-offs and extrusion with washer & other end of stand-off. Turn clockwise to secure.



<<<


Connect sides of frame by lining

up holes with snap buttons.

#### STEP 6: ATTACH LIGHTS




#### STEP 9: ATTACH STAND-OFF LADDER GRAPHICS






Attach clamp with light on top of the frame (after fabric graphic). Turn clockwise to tighten.

#### STEP 10: ATTACH LADDER TO BACKWALL WITH CLAMPS



Tube clamps will come attached to frame. Position accent in front of backwall in desired location.

#### STEP 7: ASSEMBLE STAND-OFF LADDER FRAME



## STEP 8: ATTACH COUNTER TO LADDER



3/16" HEX KEY

Using provided 3/16" hex key, rotate bolt clockwise to secure accent to top of fabric backwall.



## **Check out these related products:**

The Formulate line is a collection of stylish, ergonomically designed tabletop, 8ft, 10ft, 20ft exhibits, hanging structures, and display accessories. Formulate combines state-of-the-art zipper pillowcase dye-sublimated fabric coverings with a premium lightweight aluminum structure. Formulate is efficient, easy to assemble and disassemble, and offers remarkable style options and choices.

